

Basic Electricity


For an electrical component to function, it must meet certain essential requirements: a potential difference, a conductive path with a flow of electrons, and a load or resistance.

Potential Difference: The potential difference, or voltage, represents the electrical potential disparity between two points. It indicates the force with which electrons are driven from one point to another and is measured in volts.

Conductive Path: In electricity, a path for electrical flow is commonly known as a conductor. An electrical conductor is a material that enables the passage of electricity by allowing free electrons to move easily between atoms when voltage is applied. Metals are often excellent conductors due to the presence of free electrons in their outer atomic structure. Materials like silver, gold, copper, and steel are considered optimal conductors and are commonly found in automotive systems.

Resistance and Load: Resistance is the opposition to the flow of electrons, measured in ohms, while a load is the power required to perform work, measured in watts. An understanding of Ohm's Law helps to clarify this relationship.


Resistance in an electrical circuit is the opposition to the current flow. This opposition is determined by factors such as the material's properties, length, cross-sectional area, and temperature. When resistance is high, current flow is limited. Conversely, when resistance is low, current flow is increased. For instance, in appliances like toasters and incandescent light bulbs, high resistance in small coils or thin filaments causes the current to struggle and generate heat, resulting in the desired outcome –toasting bread or producing light.






Ohm's Law: Ohm's law defines the connection between electric current and potential difference. In most conductors, the current flowing is directly proportional to the applied voltage. This relationship is mathematically expressed as $V=IR$, where volts equals current multiplied by resistance.

In a 12-volt system, a light bulb with a resistance of 6.5 ohms will draw approximately 1.8 amps of current. This calculation is based on Ohm's Law, which states that current (I) equals voltage (V) divided by resistance (R), or $I = V/R$. Therefore, with a voltage of 12 volts and a resistance of 6.5 ohms, the current drawn by the circuit would be calculated as $12 / 6.5 = 1.8$ amps.




There's two electrical theories are commonly used: Conventional Current and Electron Flow. For this article, we will operate under the assumption that the direction of the current flow does not impact the current behavior.

Conventional Current: Conventional Current theory is current flows out of the positive terminal, travels through the circuit, and eventually returns to the negative terminal of the source. This convention was established during the early days of electricity discovery, although it has since been proven incorrect.





Electron Flow: Electron Flow theory accurately describes the movement of electrons in a circuit. Electrons flow out of the negative terminal, traverse the circuit, and ultimately enter the positive terminal of the source.



DC Voltage: DC voltage short for Direct Current Voltage, refers to voltage with a consistent polarity that drives current in a single direction through a circuit. This type of voltage can either be constant, where the voltage and polarity remain the same, or variable, where the voltage changes over time while the polarity stays constant. DC voltage is typically sourced from a cell, battery, or DC generator, among others. Due to its unchanging polarity, DC voltage has a frequency of zero.

Application in Automotive Systems: In the automotive context, a potential difference is a DC voltage battery, with electrical wires and the metal body/frame serving as conductors. A load can take the form of relays, light bulbs, electrical motors, or coils within the vehicle's electrical system.

Electrical Safety: Proper wire size, secure connections, and correctly sized fuses are essential for ensuring the safety and efficiency of a vehicle's wiring system. Undersized wires, corroded connections, and oversized fuses can lead to system failure, component damage, and potential fire hazards. It is imperative to pay attention to these factors to maintain the integrity of the vehicle's wiring system.